Nimbus MyCar Retail Mobile Application

User Guide - iOS

Version 2.0 | April 2021

Table of Contents

Overview **3**

Install App and Accessing the system **4**

To sign in to the app 4

To reset the password 5

To change the password 5

To go to customer support 7

To go to about mycar 8

To sign out of the app 9

To check vehicle list 10

Viewing vehicle current location **11**

Viewing vehicle details **12**

Viewing vehicle movement **13**

Viewing History Playback **14**

Managing Service Center **16**

Fuel Records 17

Vehicle Repair 19

Vehicle Service 21

Vehicle Insurance 23

Revenue License 25

Emission Test 27

Vehicle Settings 29

Wheel Alignment Dates 30

Service notifications and Alerts 32

Screen Descriptions **33**

Current Location/Location Tracking 33

Current Status Data 33

Movement Tracking/Vehicle Movement 33

History Playback/Vehicle History 33

Managing Service Center 33

Field & Button Descriptions 34

1 Overview

The **Nimbus MyCar** Retail Application is an easy-to-use mobile application that enables you to track & manage your personal vehicle.

You can view your vehicle's current location, current status, current movement, history data, and add vehicle service records. **MyCar** will provide notification reminders of the services your vehicle may need.

This user guide is designed to guide you through the Application by providing step-by-step instructions and all the related information that you may require.

Important:

Please note that this user guide describes the complete functionality of the **Nimbus MyCar** mobile application. Some features may be unavailable to you depending on the version of your software.

The screenshots in this manual are used to aid the understanding of the Application. Therefore, **Nimbus Venture** reserves the right to alter certain images to uphold customer confidentiality.

---

2 Install App and Accessing the system

You can sign into the **MyCar** app with the credentials received during the registration process.

2.1 Install App

Search and install the **MyCar** app from the Apple Store. Note that the publisher is **Nimbus Venture**. Then you will see the shortcut icon on the device screen.

2.2 To sign in to the app

1. Enter **Username** & **Password** received via Email/SMS during the registration process to the MyCar service and click **Login.**



2.3 To reset the password

1. Click on the Reset Password link given in the bottom of the signing window

2. Enter your **Email** address in the opening dialog box and click **Confirm**.

3. The user will receive Email/SMS with the new credentials to access the app.



2.4 To change the password

1. Click your user photo on the top-right corner of the app.

2. Click on the **Change Password** button given in the bottom of the signing window

3. Enter Old and New Passwords & save.


MYCAR
Location Tracking
Change Password
Support
About
Sign Out
AAA-0001
11.00 km/h
11:09:15 AM
Mon Apr 19
Edward Lane
School Lane
Jumma Mosque
HSBC
Laurie's Road
Majestic Ave
Mel Mawatha
Joseph's Lane
Pepin Lane
Daisy Villa Rd
Silva Lane
De Vos Avenue
Galle Road
A2
Vajira Road


Change Password
Old Password
New Password
Confirm New Password
SAVE

2.5 To go to Customer Support

1. Click your user photo on the top-right corner of the app and click **Support.**



2.6 To go to About MyCar

2. Click your user photo on the top-right corner of the app and click **About.**



2.7 To sign out of the app

3. Click your user photo on the top-right corner of the app and click **Sign Out.**



2.8 To check vehicle list

4. Click on the Vehicle photo on the top-right corner of the app**.**



3 Viewing vehicle current location

Use this procedure to view the current location of the vehicle on the map. Location data will be updated every 15 seconds.

Vehicle data will show in a pop-up. A user can always click on the vehicle to see those details.

To view the vehicle location

For field descriptions, see Current Location[Refer section 8.1]

1. On the main dashboard menu bar, select the first icon on the menu bar.
2. The exact location of the vehicle appears on a zoomed-in map.



4 Viewing vehicle details

Use this procedure to view the current status of a selected vehicle.

To view the status of a vehicle, you must select the vehicle icon which appears on the map, you can click the icon to view its details.

To view the vehicle details

For field descriptions, see Current Status Data[Refer section 8.2]

1. On the main dashboard menu bar, select the first icon(location tracking icon) on the menu bar.
2. Click the vehicle icon. The vehicle details appear in a pop-up window.



5 Viewing vehicle movement

Use this procedure to view the current movement of a vehicle.

To view movement tracking

For field descriptions, see Movement tracking Data[Refer section 8.3]

1. On the main dashboard menu bar, select the second icon(movement tracking icon) from left.

2. The vehicle details will appear on the gauge icon.

6 Viewing History Playback

Use this procedure to view the history data of a vehicle.

To view history playback

For field descriptions, see History Playback Data[Refer section 8.4]

1. On the main dashboard menu bar, select the third icon(history playback icon) from left.

2. The default setting is to play previous 6 hours of history data of the vehicle.

3. Click on the change history duration icon(on the top right of the map) again to **view** the history window. You can change the duration date and time keeping the history window to 6 hours max.

4. You can play, pause, change forward speed, backward speed, change history play-back time in this window.



Buttons

	Replay – Start to play history data from the start location
	Pause – pause and hold history play
	Forward Speed – up the playing speed
	Backward Speed – down the playing speed
	Clear History – clear history path of the reply
	Stop – stop replay and clear vehicle
	Time - change history time duration

7 Managing Service Center

This section describes how to enter service data, and add vehicle details. There are eight tracking items on this page and they are Fuel Records, Vehicle Repair, Vehicle Service, Vehicle Insurance, Revenue License, Emission Test, Vehicle Settings, and Wheel Alignment dates.

To view managing service center

For field descriptions, see Managing Service Center[Refer section 8.5]

7.1 Fuel Records

In this window, we can view, add, edit and delete fuel records of a particular vehicle.

Add fuel records

You can add new fuel records by clicking Enter details button on the bottom of the page. It will open up an Enter detail popup window. You can add the amount, date, and a special note about the data you are entering.



View fuel records

The data list will show if you have entered previous fuel records data.

Edit fuel records

Tap on the record you want to edit. It will open up a decision box. Click



Delete fuel records

Tap on the record you want to delete. It will open up a decision box. Click
It will open up a confirmation dialog box to ensure that you really want to delete that data.

Buttons

	Edit Fuel records – Opens the Update fuel record window. This window is used to modify the fuel details.
	Delete Fuel records – Deletes a fuel record.

7.2 Vehicle Repair

In this window, we can add, read, edit and delete vehicle repair records of this vehicle.

Add vehicle repair records

You can add new vehicle repair records by clicking Enter Details button on the bottom of the page. It will open up an Enter detail popup window. You can add the amount, date, and a special note about the data you are entering.



View vehicle repair records

The data list will show if you have entered previous vehicle repair records.

Edit vehicle repair records

Tap on the record you want to edit. It will open up a decision box. Click



Delete vehicle repair records

Tap on the record you want to delete. It will open up a decision box. Click
It will open up a confirmation dialog box to ensure that you really want to delete that data.

Buttons

	Edit Vehicle Repair records – Opens the Update vehicle repair window. This window is used to modify the vehicle repair details.
	Delete Vehicle Repair records – Deletes a vehicle repair record.

7.3 Vehicle Service

In this window, we can add, read, edit and delete vehicle service records of this vehicle.

Add vehicle service records

You can add new service records by clicking Enter details button on the bottom of the page. It will open up an Enter detail popup window. You can add the amount, current mileage, service date, next mileage, next service date, changes done, and a special note about the data you are entering. You can select wash, engine oil, transmission oil, air filter, oil filter, brake oil as changes done.



View vehicle service records

The data list will show if you have entered previous vehicle service data. If a service is due, it will indicate with yellow color.

Edit vehicle service records

Tap on the record you want to edit. It will open up a decision box. Click



Delete vehicle service records

Tap on the record you want to delete. It will open up a decision box. Click
It will open up a confirmation dialog box to ensure that you really want to delete that data.

Buttons

	Edit Vehicle Service records – Opens the Update service record window. This window is used to modify the vehicle service details.
	Delete Vehicle Service records – Deletes a service record.

7.4 Vehicle Insurance

In this window we can add, read, edit and delete vehicle insurance records of this vehicle.

Add vehicle insurance records

You can add new vehicle insurance records by clicking Enter details button on the bottom of the page. It will open up an Enter detail popup window. You can add the amount, current date, next date, and a special note about the data you are entering.



View vehicle insurance records

The data list will show if you have entered previous vehicle insurance data. If an insurance is due, it will indicate with yellow color.

Edit vehicle insurance records

Tap on the record you want to edit. It will open up a decision box. Click



Delete vehicle insurance records

Tap on the record you want to delete. It will open up a decision box. Click
It will open up a confirmation dialog box to ensure that you really want to delete that data.

Buttons

	Edit Vehicle Insurance records – Opens the Update vehicle insurance record window. This window is used to modify the vehicle insurance details.
	Delete Vehicle Insurance records – Deletes a vehicle insurance record.

7.5 Revenue License

In this window, we can add, read, edit and delete revenue license records of this vehicle.

Add revenue license records

You can add new revenue license records by clicking Enter details button on the bottom of the page. It will open up an Enter detail popup window. You can add the amount, date, and special note about the data you are entering.



View revenue license records

The data list will show if you have entered previous revenue license records data. If a revenue licence renewal is due, it will indicate with yellow color.

Edit revenue license records

Tap on the record you want to edit. It will open up a decision box. Click



Delete revenue license records

Tap on the record you want to delete. It will open up a decision box. Click
It will open up a confirmation dialog box to ensure that you really want to delete that data.

Buttons

	Edit Revenue License records – Opens the Update revenue license record window. This window is used to modify the revenue license details.
	Delete Revenue License records – Deletes a revenue licence record.

7.6 Emission Test

In this window, we can add, read, edit and delete emission test records of this vehicle.

Add emission test records

You can add new emission records by clicking Enter details button on the bottom of the page. It will open up an Enter detail popup window. You can add the amount, date, and a special note about the data you are entering.



View emission test records

The data list will show if you have entered previous emission test records.

Edit emission test records

Tap on the record you want to edit. It will open up a decision box. Click



Delete emission test records

Tap on the record you want to delete. It will open up a decision box. Click
It will open up a confirmation dialog box to ensure that you really want to delete that data.

Buttons

	Edit Emission records – Opens the Update emission test record window. This window is used to modify the emission test details.
	Delete Emission Test records – Deletes a emission test record.

7.7 Vehicle Settings

In this window, we can edit vehicle-related settings.

Edit vehicle settings

You can select currency & distance metrics, change maximum speed & odometer sync value.



7.8 Wheel Alignment Dates

In this window, we can add, read, edit and delete wheel alignment records of this vehicle.

Add wheel alignment records

You can add new wheel alignment records by clicking Enter details button on the bottom of the page. It will open up an Enter detail popup window. You can add the amount, current date, next mileage, and a special note about the data you are entering.



View wheel alignment records

The data list will show if you have entered previous wheel alignment records data. If your next wheel alignment is due, it will indicate you in yellow color.

Edit wheel alignment record

Tap on the record you want to edit. It will open up a decision box. Click



Delete wheel alignment record

Tap on the record you want to delete. It will open up a decision box. Click
It will open up a confirmation dialog box to ensure that you really want to delete that data.

Buttons

	Edit Wheel Alignment records – Opens the Update wheel alignment record window. This window is used to modify the wheel alignment details.
	Delete Wheel Alignment records – Deletes a wheel alignment record.

7.9 Service notifications and Alerts

Using this button you can view notifications and alerts about the service data you have saved. On the main dashboard menu bar, select the fifth icon(notification icon) from left.



8 Screen Descriptions

This section describes the functions that can be performed on each page and its respective field descriptions.

8.1 Current Location/Location Tracking

This page is used to:

- View the location of the vehicle.
- View the current status and the details of the vehicle.

8.2 Current Status Data

This page is used to:

- View vehicle current status data. It displays details such as vehicle number, current vehicle speed, time and date.

8.3 Movement Tracking/Vehicle Movement

This page is used to:

- View vehicle current movement. It displays details such as vehicle number, current vehicle speed, time.

8.4 History Playback/Vehicle History

This page is used to:

- Show vehicle history details. It provides history path of the vehicle, parking areas, high-speed locations.

8.5 Managing Service Center

This page is used to:

- View, Create, Update, and Edit data in Fuel Records, Vehicle Repair, Vehicle Service, Vehicle Insurance, Revenue Licence, Emission Test, Vehicle Settings, Wheel Alignment Dates.

8.6 Field & Button Descriptions

This page is used to:

- Show the use of the buttons, fields, and images which are used in this application.

Add account - Add another google account by entering username & password

Username- Account name you have been registered with MyCar services.

Password - Password you got from the email or text message

Reset Password - Reset the password for the **MyCar** login account

Change password - Change the password of the signing account

Old Password - Old password you have been using until now

New Password - Enter the new password you want to save

Confirm New Password - Enter the new password you want to save again

- Loads the location tracking page

- Loads the movement tracking page

- Loads the history playback page

- Loads the service center page

- Shows alerts if there is any

- Open sign out button

- Open vehicle list button



- Sign out from MyCar

- Show vehicle number, vehicle speed, time in movement & history playback

From Date – To Date: The time period for which the data is required

From Time – To Time: The specific clocking times for which the data is required

- Hide history date time view or get historical data for the selected date time



- Show playback currently playing speed

- Clear history playback path from the map

- Reduce playback speed

- Play history

- Pause history playback

- Increase playback speed

- Stop history playback

- Show history duration dates & time pop up

- Show fuel records

- Show vehicle repair records

- Show vehicle service records

- Show vehicle insurance records

- Show revenue license records

- Show emission test records

- Show vehicle settings

- Show wheel alignment date records

- Edit a record

- Delete a record

- Close popup dialogue box

- Opens up enter details dialogue box in service center

- Save records in service center

- Close delete record dialogue box

- Delete a service record

- Close delete record dialogue box

- Vehicle's current status data is more than 5 minutes old. Something is wrong

-Device is not powered properly

Date: A date value for the entering record

Amount: A currency amount which a user spends for a service

Special Remarks: A description about the service data

Current Mileage: Current mileage of the vehicle

Service Date: Date value of the service has done

Next Mileage: Mileage of the vehicle when the service is due

Next Service Date: Date value of the service to be done

Changes Done: To chose which services are done

Wash: Vehicle has done wash

Engine Oil: Vehicle has changed engine oil

Transmission Oil: Vehicle has changed transmission oil

Air Filter: Vehicle has changed air filters

Oil Filter: Vehicle has changed oil filters

Brake Oil: Vehicle has changed brake oil

Current Date: A date value when the service has done

Next Date: A date value when the service has to be done

Vehicle Number: Vehicle number to use as the default vehicle

Currency: Select a currency value you want to save service data

Distance: Select a metric to save service data mileage

Max Speed: A safe speed for a vehicle to travel

Odometer Sync Value: Odometer reading before the device installation